

SDM630MCT-2T

DIN Rail Smart Energy Meter for Single and Three Phase Electrical Systems



- Measures kWh Kvarh, KW, Kvar, KVA, PF, Hz, dmd, V, A, etc.
- Bi-directional measurement IMP & EXP
- Two pulse outputs
- RS485 Modbus
- Din rail mounting 35mm
- 1A/5A CT connection
- Better than Class 1 / B accuracy

USER MANUAL

2022 V2.5

Important Safety Information is contained in the Maintenance section. Familiarize yourself with this information before attempting installation or other procedures.

Symbols used in this document:



Risk of Danger: These instructions contain important safety information:
Read them before starting installation or servicing of the equipment



Caution: Risk of Electric Shock

1 Introduction

This document provides operating, maintenance and installation instructions. The unit SDM630MCT-2T V2 measures and displays the characteristics of single phase two wires(1p2w), three phase three wires(3p3w,) and three phase four wires(3p4w) supplies, including KWh, kVarh, KW, KVar, KVA, PF, Frequency, Voltage, Current, dmd. THD etc. Energy is measured in terms of kWh, kVarh. Maximum demand current can be measured over preset periods of up to 60minutes. The requisite current input(s) are obtained via current transformers(CT).

This meter can be configured to work with a wide range of CTs,giving the unit a wide range of operation.Built-in interfaces provide pulse and RS485 Modbus RTU outputs.Configuration is password protected.

This unit has 2 source powers and can show energy of T1 and T2. If you want to shift T1 to T2, as far as there is 230V load between terminal 7 and 8 ,the meter will count up to T2. The pulse output 1 and pulse output2 is switched automatically when the power is input.

1.1 Unit Characteristics

The unit can measure and display:

- Line voltage and THD% (total harmonic distortion) of all phases
- Line Frequency
- Currents, Current demands and current THD% of all phases
- Power, maximum power demand and power factor
- Active energy imported and exported
- Reactive energy imported and exported

The unit has password-protected set-up screens for:

- Changing password
- Supply system selection 1p2w, 3p3w,3p4w
- Demand Interval time
- Reset for demand measurements
- Pulse output duration

Two pulse outputs indicate real-time energy measurement. A RS485 output allows remote monitoring from another display or a computer.

1.2 Current Transformer Primary Current

The unit can be configured to operate with CT ratio between primary current and secondary current. The secondary CT has two options: 1A/5A.

**Please note for the MID approved version, you will only have one opportunity to set the CT ratio.*

1.3 RS485 Serial – Modbus RTU

This unit uses a RS485 serial port with Modbus RTU protocol to provide a means of remotely monitoring and controlling the unit.

Set-up screens are provided for setting up the RS485 port. Refers to section 4.8.


1.4 Pulse output

Zhejiang Eastron Electronic Co.,Ltd. [Tel:0086-573-83698881](tel:0086-573-83698881) Email:sales@eastrongroup.com

Add: No.1369. Chengnan Road, Nanhu District, Jiaxing City, Zhejiang, China 314001.

This unit provides two pulse outputs that clock up measured T1 active energy and T2 active energy. The default constant for active energy is 3200imp/kWh. The pulse width for active energy can be set from the set-up menu.

2. Start Up Screens

	The first screen lights up all display segments and can be used as a display check.
	The second screen indicates the firmware installed in the unit and its build number.
	The interface performs a self-test and indicates the result if the test passes.

*After a short delay, the screen will display active energy measurements.

3. Measurements

The buttons operate as follows:

	Selects the Voltage and Current display screens In Set-up Mode, this is the “Left” or “Back” button.
	Select the Frequency and Power factor display screens In Set-up Mode, this is the “Up” button
	Select the Power display screens In Set-up Mode, this is the “Down” button
	Select the Energy display screens In Set-up mode, this is the “Enter” or “Right” button

3.1 Voltage and Current

Each successive pressing of the  button selects a new range:

L^1 L^2 L^3 000.0 V 000.0 V 000.0 V	Phase to neutral voltages
L^{1-2} L^{2-3} L^{3-1} 380.0 V 380.0 V 380.0 V	Phase to neutral voltages
L^1 L^2 L^3 0.000 A 0.000 A 0.000 A	Current on each phase
N 0.000 A	Current on netural
L^1 L^2 L^3 00.00 V %THD 00.00 V %THD 00.00 V %THD	Phase to neutral voltage THD%

L¹ 00.00 L² 00.00 L³ 00.00 I%THD	Current THD% for each phase
---	-----------------------------

3.2 Frequency and Power factor and Demand

Each successive pressing of the  button selects a new range:

Σ 00.00 Hz 0.999 PF	Frequency and Power Factor (total)
L¹ 0.999 L² 0.999 L³ 0.999 PF	Power Factor of each phase
MD L¹ 0.0000 L² 0.0000 L³ 0.0000 A	Maximum Current Demand
MD 0.0000 kW Σ	Maximum Power Demand

3.3 Power

Each successive pressing of the  button select a new range:

L¹ L² L³ 0.0000 0.0000 0.0000 kW	Instantaneous Active Power in kW
L¹ L² L³ 0.0000 0.0000 0.0000 kVAr	Instantaneous Reactive Power in kVAr
L¹ L² L³ 0.0000 0.0000 0.0000 kVA	Instantaneous Volt-amps in KVA
Σ 0.0000 0.0000 0.0000 kW kVAr kVA	Total kW, kVArh, kVA

3.4 Energy Measurements

Each successive pressing of the  button selects a new range:

Σ 0000 031.4 kWh	Total active energy in kWh
---	----------------------------

	Total reactive energy in kVarh
	T1 active energy in kWh When T1 working, the symbol “ T1” will be flashing
	T2 active energy in kWh When T2 working, the symbol “ T2” will be flashing
	T1 reactive energy in kVarh When T1 working, the symbol “ T1” will be flashing
	T2 reactive energy in kVarh When T2 working, the symbol “ T2” will be flashing

4. Setting Up

To enter set-up mode, pressing the  button for 3 seconds, until the password screen appears.



Setting up is password-protected so you must enter the correct password (default '1000') before processing. If an incorrect password is entered, the display will show: PASS Err



To exit setting-up mode, press  repeatedly until the measurement screen is restored.

4.1 Set-up Entry Methods

Some menu items, such as password and CT, require a four-digit number entry while others, such as supply system, require selection from a number of menu options.

4.1.1 Menu Option Selection

1) Use the  and  buttons to select the required item from the menu shown in section 4.1. selection does not roll over between bottom and top of list

2) Press  to confirm your selection

3) If an item flashes, then it can be adjusted by the  and  buttons. If not, there maybe a further layer.

4) Having selected an option from the current layer, press  to confirm your selection. The SET indicator will appear.

5) Having completed a parameter setting, press  to return to a higher menu level. The SET indicator will be removed and you will be able to use the  and  buttons for further menu selection.

6) On completion of all setting-up, press  repeatedly until the measurement screen is restored.

4.1.2 Number Entry Procedure

When Setting up the unit , some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:

- 1) The current digit to be set flashes and is set using the  and  buttons
- 2) Press  to confirm each digit setting. The SET indicator appears after the last digit has been set.
- 3) After setting the last digit, press  to exit the number setting routine. The SET indicator will be removed.

4.2 Communication

There is a RS485 port can be used for communication using Modbus RTU protocol.
For Modbus RTU, parameters are selected from front panel.

4.2.1 RS485 Address





(The range is from 001 to 247)

	From the Set-up menu, use  and  buttons to select the Address ID
	Press  button to enter the selection routine. The current setting will be flashing.

	Use  and  buttons to choose Modbus Address(001 to 247)
On completion of the entry procedure, press  button to confirm the setting and press  button to return the main set-up menu.	

4.2.2 Baud Rate

	From the Set-up menu, use  and  buttons to select the Baud Rate option.
	Press  to enter the selection routine. The current setting will flash.
	Use  and  buttons to choose Baud rate 2.4k, 4.8k, 9.6k, 19.2k, 38.4k
On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.	

4.2.3 Parity

	From the Set-up menu, use  and  buttons to select the Parity option.
	Press  to enter the selection routine. The current setting will flash.
	Use  and  buttons to choose Parity (EVEN / ODD / NONE)
On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.	

4.2.4 Stop bits

	From the Set-up menu, use  and  buttons to select the Stop Bit option.
	Press  to enter the selection routine. The current setting will flash.

	Use  and  buttons to choose Stop Bit (2 or 1)
On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.	

4.3 CT

The CT option sets the secondary current(CT2 1A or 5A) of the current transformer (CT) that wires to the meter.

	From the Set-up menu, use  and  buttons to select the CT option.
	Secondary CT setting Press  to enter the CT secondary current selection routine.:5A/1A
	Set CT Ratio value Press  to enter the CT Ratio setting screen.The range is from 0001 to 9999.
For example,if set the ratio to be 100,it means the primary current equals secondary currentx100. <i>*Please note for the MID approved version, you will only have one opportunity to set the CT ratio.</i>	

4.4 PT

The PT option sets the secondary voltage (PT2 100 to 500V) of the Voltage transformer (PT) that wires to the meter.

Zhejiang Eastron Electronic Co.,Ltd. [Tel:0086-573-83698881](tel:0086-573-83698881) Email:sales@eastrongroup.com


Add: No.1369. Chengnan Road, Nanhu District, Jiaxing City, Zhejiang, China 314001.

	From the Set-up menu, use  and  buttons to select the PT option. The screen will show the voltage PT secondary voltage value. The default value is 400V
	Secondary PT setting Press  to enter the PT secondary voltage selection routine. The range is from 100 to 500V
	Set PT ratios value Press  to enter the PT ratio screen. The range is from 0001 to 9999
For example, if set the ratio to be 100, it means the primary voltage equals secondary voltage x 100	

4.5 Pulse Output

4.5.1 Pulse output type

1		From the Set-up menu, use  and  buttons to select the Pulse output option.
2-1		Press  to enter the selection routine. The unit symbol will flash.

2-2		Use  and  buttons to choose kWh or kVArh.
On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.		

4.5.2. Pulse rate

Use this to set the energy represented by each pulse. Rate can be set to 1 pulse per 0.01kWh/0.1kWh/1kWh/10kWh/100/1000kWh.



(It shows 1 impulse = 10kWh/kVArh)

1		From the Set-up menu, use  and  buttons to select the Pulse Rate option.
2		Press  to enter the selection routine. The current setting will flash. 0.01/0.1/1/10/100/1000kWh/kVArh per pulse
Use  and  buttons to choose pulse rate. On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.		

4.5.3 Pulse Duration

The energy monitored can be active or reactive and the pulse width can be selected as 200, 100 or 60ms.



(It shows pulse width of 200ms)

	From the Set-up menu, use  and  buttons to select the Pulse width option.
	Press  to enter the selection routine. The current setting will flash.
Use  and  buttons to choose pulse width. On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.	

4.6 DIT Demand Integration Time

This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are: off, 5, 10, 15, 30, 60 minutes

	From the set-up menu, use  and  buttons to select the DIT option. The screen will show the currently selected integration time.
---	--



	Press  to enter the selection routine. The current time interval will flash
	Use  and  buttons to select the time required.
	Press  to confirm the selection. SET indicator will appear.
Press  to exit the DIT selection routine and return to the menu.	

4.7 Backlit setup

1		The backlit lasting time is settable Default lasting time is 60minutes For example, if it's set as 5, the backlit will be off in 5minutes from the last time operation on the meter.
2		Press  to enter the selection routine. The current time interval will flash The options can be: 0(always on),5,10,30,60,120minutes
Use  and  buttons to select the time required. Press  to confirm the set-up,		

4.8 Supply System

Use this section to set the type of power supply being monitored.

	From the Set-up menu, use  and  buttons to select the System option. The screen will show the currently selected power supply .
	Press  to enter the selection routine. The current selection will flash
	Use  and  buttons to select the required system option: 1P2(W),3P3(W) ,3P4(W)
	Press  to confirm the selection. SET indicator will appear.
Press  to exit the system selection routine and return to the menu. SET will disappear and you will be returned to the main Set-up Menu	

4.9 CLR

The meter provides a function to reset the maximum demand value of current and power.

	From the Set-up menu, use  and  buttons to select the reset option.
---	--

	Press  to enter the selection routine. The MD will flash.
Press  to confirm the setting and press  to return to the main set up menu.	

4.10 Change password


	Use the  and  to choose the change password option
	Press the  to enter the change password routine. The new password screen will appear with the first digit flashing
	Use  and  to set the first digit and press  to confirm your selection. The next digit will flash.
	Repeat the procedure for the remaining three digits

	After setting the last digit, SET will show.
Press  to exit the number setting routine and return to the Set-up menu. SET will be removed	

4.11 Reverse connected current inputs correction set-up

1		use  and  buttons to select page "SET sys cont"
2-1		Press to  enter Phase A , the default is Frd (forward)
2-2		use  and  buttons to Phase B or C setting pages

4.11.1 How to operate if phase A is reversely connected

1		Go to phase A setting page
---	---	----------------------------

2		Press  to enter the selection routine. The Frd will flash. Use  button to change Frd to Rev.
Press  to confirm the setting and press  to return to the main set up menu.		

5 Specifications

5.1 Measured Parameters

The unit can monitor and display the following parameters of a single phase two wire(1p2w), three phase three wire(3p3w) or four phase four wire(3p4w) supply.

5.1.1 Voltage and Current

Phase to neutral voltages 85 to 276V a.c. (not for 3p3w supplies)

Voltages between phases 147 to 478V a.c. (3p supplies only)

Percentage total voltage harmonic distortion (THD%) for each phase to N (not for 3p3w supplies)

Percentage voltage THD% between phases (three phase supplies only)

Current THD% for each phase

5.1.2 Power factor and Frequency and Max. Demand

Frequency in Hz

Instantaneous power:

Power 0 to 3600 MW

Reactive Power 0 to 3600 MVar

Volt-amps 0 to 3600 MVA

Maximum demanded power since last Demand reset Power factor

Maximum neutral demand current, since the last Demand reset (for three phase supplies only)

5.1.3 Energy Measurements

- Imported/Exported active energy 0 to 9999999.9 kWh
- Imported/Exported reactive energy 0 to 9999999.9 kVarh
- Total active energy 0 to 9999999.9 kWh
- Total reactive energy 0 to 9999999.9 kVarh

5.2 Measured Inputs

Voltage inputs through 4-way fixed connector with 2.5mm² stranded wire capacity. single phase two wire(1p2w), three phase three wire(3p3w) or four phase four wire(3p4w) unbalanced. Line frequency measured from L1 voltage or L3 voltage.

Three current inputs (six physical terminals) with 2.5mm² stranded wire capacity for connection of external CTs. Nominal rated input current 5A or 1A a.c. Rms.

5.3 Accuracy

- Voltage 0.5% of range maximum
- Current 0.5% of nominal
- Frequency 0.2% of mid-frequency
- Power factor 1% of unity (0.01)
- Active power (W) $\pm 1\%$ of range maximum
- Reactive power (VAR) $\pm 2\%$ of range maximum
- Apparent power (VA) $\pm 1\%$ of range maximum
- Active energy (Wh) Class 1 IEC 62053-21
- Reactive energy (VARh) $\pm 2\%$ of range maximum
- Total harmonic distortion 1% up to 31st harmonic
- Temperature co-efficient Voltage and current = 0.013%/°C typical
Active energy = 0.018%/°C, typical
- Response time to step input 1s, typical, to >99% of final reading, at 50 Hz.

5.4 Auxiliary Supply

Two-way fixed connector with 2.5mm² stranded wire capacity.

85 to 275V a.c. 50/60Hz $\pm 10\%$ or 120V to 380V d.c. $\pm 20\%$. Consumption < 10W.

5.5 Interfaces for External Monitoring

Three interfaces are provided:

- an RS485 communication channel that can be programmed for Modbus RTU protocol
- a pulse output indicating real-time measured energy.(configurable)
- a pulse output 3200imp/kWh (not configurable)

The Modbus configuration (Baud rate etc.) and the pulse relay output assignments (kW/kVAh, import/export etc.) are configured through the Set-up screens.

5.6.1 Pulse Output

The pulse output can be set to generate pulses to represent kWh.

Rate can be set to generate 1 pulse per:

0.01 = 10 Wh/VAh

0.1 = 100 Wh/VAh

1 = 1 kWh/kVAh

10 = 10 kWh/kVAh

100 = 100 kWh/kVAh

Pulse width 200/100/60 ms.

Relay Rating 230V ac 50mA

Pulse width: 200/100(default)/60ms

Pulse output 2 is non-configurable. It is fixed up with total kWh. The constant is 3200imp/kWh.

5.6.2 RS485 Output for Modbus RTU

For Modbus RTU, the following RS485 communication parameters can be configured from the Set-up menu:

Zhejiang Eastron Electronic Co.,Ltd. [Tel:0086-573-83698881](tel:0086-573-83698881) Email:sales@eastrongroup.com

Add: No.1369. Chengnan Road, Nanhu District, Jiaxing City, Zhejiang, China 314001.

Baud rate 2400, 4800, 9600, 19200, 38400

Parity none(default)/odd/even

Stop bits 1 or 2

RS485 network address *nnn* – 3-digit number, 1 to 247

Modbus™ Word order Hi/Lo byte order is set automatically to normal or reverse. It cannot be configured from the set-up menu.

5.7 Reference Conditions of Influence Quantities

Influence Quantities are variables that affect measurement errors to a minor degree. Accuracy is verified under nominal value (within the specified tolerance) of these conditions.

- Ambient temperature 23°C ±1°C
- Input waveform 50 or 60Hz ±2%
- Input waveform Sinusoidal (distortion factor < 0.005)
- Auxiliary supply voltage Nominal ±1%
- Auxiliary supply frequency Nominal ±1%
- Auxiliary supply waveform (if AC) Sinusoidal (distortion factor < 0.05)
- Magnetic field of external origin Terrestrial flux


5.8 Environment

- Operating temperature -25°C to +55°C*
- Storage temperature -40°C to +70°C*
- Relative humidity 0 to 90%, non-condensing
- Altitude Up to 2000m
- Warm up time 1 minute
- Vibration 10Hz to 50Hz, IEC 60068-2-6, 2g


5.9 Mechanics

- DIN rail dimensions 72 x 94.5 mm (WxH) per DIN 43880
- Mounting DIN rail (DIN 43880)
- Sealing IP20 (minimum)
- Material Self-extinguishing UL 94 V-0

6. Dimensions



3) Three phase four wire



If you have any question, please feel free to contact us at:

Zhejiang Eastron Electronic Co., Ltd.
NO.1369 Chengnen Road, Jiaxing, Zhejiang, China

Email: sales@eastrongroup.com

Tel: 86-0573-83698881

Web: www.eastrongroup.com