

# my-PV WiFi Meter: Assembly- and Operation Manual

Last update: 13.8.2025, 08:17

Firmware version:

## Contents

---

### **1 Intended use**

---

### **2 Scope of delivery**

---

### **3 Indicator elements**

---

### **4 Wiring and WLAN commissioning**

---

### **5 Wiring of the my-PV WiFi Meter for Modbus RTU**

---

### **6 Web-Interface**

---

### **7 Modbus TCP communication registers**

---

### **8 Technical specifications**

---

### **9 EU Declaration of Conformity**

---

### **10 Disposal**

---

1. Intended use

The my-PV WiFi Meter is intended for operation with my-PV devices such as AC•THOR 9s, AC•THOR or AC ELWA-E.

## 2. Scope of delivery


- my-PV WiFi Meter
- 3 external current transducers
- Quickstart guide

### **⚠ Safety notice**

- The installation must be carried out exclusively by the authorized expert. When installing and connecting the relevant standards must be observed.
- Connect the current transducers to the my-PV WiFi Meter first, afterwards attach to the wires!  
Another approach could lead to the induction of dangerous voltages in the metering leads and/or damage the current transducers!
- Any damage caused by ignoring the manuals is not covered by the manufacturer's warranty.
- my-PV does not recommend connecting the meter to the Internet via port forwarding.

## 3. Indicator elements

A green LED ("RUN") on the my-PV WiFi Meter indicates that the voltage supply is present. A voltage of 230 V must be present between UN and at least one of the three terminal points UA, UB or UC. A red LED ("WIFI") on the my-PV WiFi Meter indicates that the device is connected to a WLAN. See next section.



#### 4. Wiring and WLAN commissioning

Find all Details in the Quickstart guide [here](#).

#### Tip

- When mounting the current transducers, ensure correct phase assignment!
- When mounting the current transducers, pay attention to the correct direction!


#### 5. Wiring of the my-PV WiFi Meter for Modbus RTU

**Connection possible from WiFi meter serial number: 230505XXXX!**

**Firmware version e0001301 required!**

On the AC-THOR or the AC ELWA 2, "my-PV WiFi Meter (Modbus RTU)" must be set as the control in the settings on the device.

The wiring should be done as follows.




## Tip

- Use shielded twisted pair cable! (CAT cable)
- Install a 120 Ohm terminating resistor on the RTU bus!  
(Included in the scope of delivery of the AC ELWA 2)

## 6. Web-Interface

The my-PV web interface of AC•THOR, AC•THOR 9s and AC ELWA-E is also suitable for the my-PV WiFi Meter in the same way. A search program for finding the my-PV WiFi Meter in the network and for downloading the web interface can be found [here](#). The Web-Interface can also be downloaded directly [here](#).

Please note that the display and setting options may change with more recent software versions.



At Info ("i") the current measured variables and energy quantities for all three phases are displayed.

The screenshot shows the configuration interface for a my-PV WiFi Meter. At the top, there are icons for signal strength, info, home, settings, and help. The title bar reads "my-PV Meter 2204260001 (192.168.2.21)". Below the title bar are language selection buttons for English, German, French, and Spanish. The main content area is divided into sections:

- IP Settings:** Displays MAC address (B0-F8-93-37-1C-89), Current IP address (192.168.2.21), Current subnet mask (255.255.0.0), Current gateway (192.168.2.1), Current DNS (192.168.2.1). It includes a note about using static IP only if familiar with network administration. Buttons for "Save" and "DHCP" (selected) or "Static IP" are shown.
- Basic Settings:** CT-clamp primary current dropdown set to "75A my-PV Standard". A "Save" button is present.
- Firmware Version:** Firmware Version (x.75.97), Serial No. (2204260001), "Reboot Device" button, and "Factory Reset" button.

At the bottom right, the text reads: "© 2020 my-PV GmbH, Austria. All Rights reserved. www.my-pv.com".

At Settings ("gearwheel symbol") you get to the following setting options:

## IP Settings

DHCP: By default, DHCP is enabled, i.e. the device receives an IP address from the router to which it is connected during WLAN commissioning.

Static IP: Later, the dynamic IP address can be changed to a static IP address. The settings must be adapted to the router, otherwise the device is not visible in the network!

## Basic Settings

3 current transducers ("CT terminals") for a measuring range of 0 - 75 amperes are included in the scope of delivery of the my-PV WiFi Meter ex works. No setting needs to be changed to use these transformers.

For measuring currents above 75 amps, it is possible to use other current transducers. There are different sizes of my-PV available. Please contact my-PV: [info@my-pv.com](mailto:info@my-pv.com)

The screenshot shows the "Basic Settings" section with a dropdown menu for "CT-clamp primary current". The menu options are:

- 75A my-PV Standard
- 100A my-PV (highlighted with a red box)
- 200A my-PV
- 400A my-PV
- 600A my-PV
- other

The screenshot shows the "Firmware Version" section with the following information:

- Firmware Version: x.75.97
- Serial No.: 2204260001
- Buttons: "Reboot Device" and "Factory Reset".

As a third option the use of third party transducers is possible, where the ratio of primary to secondary current of the transformers has to be adjusted. Please contact my-PV: [support@my-pv.com](mailto:support@my-pv.com)

## ⚠ Attention!


The maximum secondary current must not exceed 125 mA!

### ▲ Basic Settings

CT-clamp primary current:

CT clamp current primary/secondary:  
Maximal secondary winding current must not exceed 125mA.

CT clamp ratio:



## Firmware Version

In this area, the installed firmware versions can be viewed (for service and update purposes). A firmware update is neither automatic nor provided by the plant operator. If required, you can obtain further information here: [support@my-pv.com](mailto:support@my-pv.com). Please specify the 10-digit serial number of the my-PV WiFi Meter when contacting us.

The "Reboot device" button restarts the my-PV WiFi Meter.

The "Factory Reset" button resets the settings of the device to the factory settings.

## 7. Modbus TCP communication registers

The my-PV WiFi Meter also offers an open data interface.

The communication registers can be queried by superordinated controllers, for example.

Device ID: 1

Device Port: 502

Register range: Holding registers

Note: When using my-PV current transducers in special sizes (100A, 200A, 400A, 600A), the measured values of the registers are not automatically corrected.

Therefore multiply the currents / powers by the corresponding CT factor, i.e. in the case of 200A with 200A/75A = 2.6667.

index	Register address(Dec)	Register address(Hex)	register length	Description
1	0	0000	1	Phase A voltage,unsigned,value=data/100,unit: V
2	1	0001	1	Phase A current,unsigned,value=data/100,unit: A
3	2	0002	2	Phase A active power,signed,value=data/unit: W
4	4	0004	2	Phase A forward energy,unsigned,value=data/800,unit:kWh
5	6	0006	2	Phase A reverse energy,unsigned,value=data/800,unit:kWh
6	8	0008	1	Phase A power factor,unsigned,value=data/1000
7	9	0009	1	PadA ox00,not used
8	10	000A	1	Phase B voltage,unsigned,value=data/100,unit: V
9	11	000B	1	Phase B current,unsigned,value=data/100,unit: A
10	12	000C	2	Phase B active power,signed,value=data/unit: W
11	14	000E	2	Phase B forward energy,unsigned,value=data/800,unit:kWh
12	16	0010	2	Phase B reverse energy,unsigned,value=data/800,unit:kWh
13	18	0012	1	Phase B power factor,unsigned,value=data/1000
14	19	0013	1	PadB ox00,not used
15	20	0014	1	Phase C voltage,unsigned,value=data/100,unit: V
16	21	0015	1	Phase C current,unsigned,value=data/100,unit: A
17	22	0016	2	Phase C active power,signed,value=data/unit: W
18	24	0018	2	Phase C forward energy,unsigned,value=data/800,unit:kWh
19	26	001A	2	Phase C reverse energy,unsigned,value=data/800,unit:kWh
20	28	001C	1	Phase C power factor,unsigned,value=data/1000
21	29	001D	1	PadC ox00,not used
22	30	001E	1	frequency,unsigned,value=data/100,unit:Hz
23	31	001F	1	padff ox00,not used
24	32	0020	2	sum of power, signed, value=data, unit:W
25	34	0022	2	sum of forward energy,unsigned,value=data/800,unit:kWh
26	36	0024	2	sum of reverse energy,unsigned,value=data/800,unit:kwh

## 8. Technical specifications

You can find them at any time [here](#).

## 9. EU Declaration of Conformity

You can find them at any time [here](#).

## 10. Disposal

Either keep packing material or dispose properly.

Dispose of the product at the end of its service life in accordance with the applicable regulations.